banky

USER MANUAL

Rechargeable Flashlight with 10,000 mAh Power Bank

12,000 lumens | zoom up to 500 m | 10,000 mAh | USB-C 22.5W | IP46



Please read this manual before first use and keep it for future reference.

EAN 8720865564944

banky.nl

Welcome to Banky

Thank you for choosing the Banky Rechargeable Flashlight with 10,000 mAh Power Bank. A super bright LED flashlight with a zoom head and a built-in power bank in one sturdy aluminium housing. This manual explains how to charge it, how to use the light modes, how to charge your phone with it and how to keep it working well for years.

In the box

Flashlight with power bank · Lanyard · This manual

Product overview



1. Zoom head with LED light
2. Power button with 4 battery indicator lights
3. Rear end with work light

Specifications

Item	Value
Brightness	Up to 12,000 lumens
Range	Up to 500 m
Light modes	5: high, medium, low, strobe and rear work light
Zoom	Sliding head: long-range beam or wide flood
Capacity	10,000 mAh / 37Wh (3 × 18650 cells)
USB-C (in and out)	Up to 22.5W
Battery level	4 lights in the power button
Waterproof	IP46, resistant to rain and water jets
Housing	Aluminium
Length	26.5 cm
Weight	628 grams

Specifications are subject to change without notice.

Quick start

1. Fully charge the flashlight via the USB-C port before first use. When all 4 lights are on, it is full.
2. Press the power button to switch the light on. Press again to move to the next light mode.
3. Turn or slide the head to choose between a long-range beam and a wide flood.

The light modes

- **High:** maximum light, up to 12,000 lumens.
- **Medium:** for everyday use.
- **Low:** hours of light, for example in a tent.
- **Strobe:** flashing light to stand out or as an emergency signal.
- **Work light:** the extra light at the rear, handy for working or as ambient light.

Long or wide: the zoom head

Slide the head forward for a focused beam that reaches up to 500 metres. Slide it back for a wide flood that lights up everything around you.

Charging the flashlight

Connect a USB-C cable to the USB-C port and to a USB-C adapter of at least 20W. The 4 lights in the button show the charging progress. When all lights stay on, it is full.

Charging your phone

Connect your phone to the USB-C port of the flashlight with a USB-C cable. Charging starts automatically, with fast charging up to 22.5W. A full battery charges an iPhone about 2 times. The flashlight and your phone agree on the speed together: your phone never takes more than it can handle.

Capacity and power

mAh and Wh tell you how much energy fits in the power bank: 10,000 mAh equals 37Wh. W (watts) tells you how fast that energy goes in or out. 'Up to 22.5W' is the maximum, with a suitable cable and a device that asks for that much. How fast your device actually charges depends on the port, the cable and the device itself. Some energy is always lost during conversion, so not all stored energy ends up in your device.

The first three times: calibration

On a new power bank the battery level display can jump a little at first. For the best results we recommend letting it complete three full cycles. This helps the cells and the protection chip get properly attuned to each other.

1. Use the power bank until it is completely empty and switches itself off.
2. Then charge it fully to 100% straight away, without interruption via USB-C.
3. Repeat this twice more, so three full cycles in total.

After that the battery level is usually shown more accurately. You do not need to run it empty every time afterwards.

Getting the most out of your flashlight

Everyday use

- Topping it up whenever it suits you is fine. There is no need to wait until it is empty.
- Do not leave it completely empty for weeks or months. A battery left at 0% for a long time can discharge so deeply that it will no longer charge.
- It is normal for it to get slightly warm while charging. Place it on a hard, open surface and do not cover it.
- Do not leave the light on its highest setting unnecessarily: it uses a lot of energy and makes the head warm.

Storing it for a longer period

- Store it at about half charge (40 to 60%). This is the most relaxed state for a lithium battery.
- Top it up at least every 60 days, even when you are not using it.
- Keep it dry and at room temperature. Not in a hot car, in direct sunlight or next to a heater.

Cleaning

Use a soft, dry cloth. No water, detergents or solvents. Disconnect all cables first.

Safe use

Please read these points before use. Ignoring them may result in injury, fire or damage to the product.

- Keep the flashlight out of reach of children and only use it as described in this manual.
- The flashlight is waterproof to IP46: rain and water jets will not harm it. Do not immerse it and do not use it underwater.
- Do not use it outside 0 to 45 °C. Keep it away from heat sources and open flames.
- Do not use a damaged, deformed or swollen flashlight, or damaged cables.

- Do not insert objects into the ports, do not short-circuit them, do not drop it and do not open it yourself.
- Do not look directly into the light and do not shine it into the eyes of people or animals. The light is extremely bright.
- The head can get warm on the highest setting. Do not place the lit flashlight on fabric, paper or your skin.
- Notice smoke, a strange smell or strong heat? Disconnect all cables immediately and stop using it. Please contact us.
- Never throw the flashlight into a fire: it may explode.

Allowed in hand luggage

This power bank has 37Wh. Power banks up to 100Wh may be taken on board in your hand luggage under IATA rules. Not in checked baggage. Always check the rules of your airline before you travel.

Troubleshooting

Problem	Solution
Light does not switch on	The battery is probably empty. Charge it via USB-C and try again.
Light is less bright	Brightness drops when the battery is low. Charge it. Also check that the lens is clean.
Phone does not charge	Push the cable firmly into both ends and use a good USB-C cable. Is the flashlight almost empty? Charge it first.
Flashlight does not charge	Try another cable or adapter. An adapter of at least 20W charges fastest.
Head gets warm	Normal on the highest setting. Switch back to medium or low.

Warranty and customer service

Your Banky is covered by the statutory warranty. Have a question, or is something not working as it should? Our team is happy to help. Email **info@banky.nl** and include your order number and the model of your flashlight.

Disposal at the end of its life

Do not dispose of the flashlight with household waste. Take it to a collection point for batteries and electronics so the materials can be reused.

banky

Questions about your flashlight?
info@banky.nl

Thank you for choosing Banky. Energetic regards, Team Banky