banky

USER MANUAL

Waterproof Flashlight with 5,000 mAh Power Bank

2,200 lumens | up to 1,000 m | 5,000 mAh | 22.5W | IP65 | 6 light modes



Please read this manual before first use and keep it for future reference.

EAN 8720865564937

banky.nl

Welcome to Banky

Thank you for choosing the Banky Waterproof Rechargeable Flashlight with 5,000 mAh Power Bank. A compact, bright LED flashlight with a zoom head, rear light and a built-in power bank. Small enough to fit in your coat pocket. This manual explains how to charge it, how to use the light modes and how to charge your phone with it.

In the box

Flashlight with power bank · Lanyard · This manual

Product overview



1. Zoom head with LED light
2. Power button with charging light
3. Rear light and lanyard loop

The USB-C input (charging the flashlight) and the USB-A output (charging your phone) are located next to each other.

Specifications

Item	Value
Brightness	Up to 2,200 lumens
Range	Up to 1,000 m
Light modes	6: bright, soft and strobe at the front; white, red and flashing red rear light
Zoom	Sliding head
Capacity	5,000 mAh / 18.5Wh
USB-A (output)	Up to 22.5W
USB-C (input)	Charges the flashlight, about 4 hours
Waterproof	IP65, resistant to rain and water jets
Dimensions	150 × 48 × 45 mm
Weight	178 grams

Specifications are subject to change without notice.

Quick start

1. Fully charge the flashlight via USB-C before first use. The charging light in the button shows that it is charging.
2. Briefly press the power button for the front light. Press again to switch between bright, soft and strobe.
3. Press and hold the button for the rear light. Press briefly to switch between white, red and flashing red.

Long or wide: the zoom head

Slide the head forward for a long-range beam of up to 1,000 metres. Slide it back for a wide flood. The light is constant, without flicker.

Charging the flashlight

Connect a USB-C cable to the USB-C input and to a USB-C adapter. It is full in about 4 hours. The charging light in the button shows that it is charging.

Charging your phone

Connect your phone to the USB-A output using your phone's charging cable. Charging starts automatically, with fast charging up to 22.5W. Works with iPhone and Android. Your phone never takes more than it can handle.

The first three times: calibration

On a new power bank the battery level display can jump a little at first. For the best results we recommend letting it complete three full cycles. This helps the cells and the protection chip get properly attuned to each other.

1. Use the power bank until it is completely empty and switches itself off.
2. Then charge it fully to 100% straight away, without interruption via USB-C.
3. Repeat this twice more, so three full cycles in total.

After that the battery level is usually shown more accurately. You do not need to run it empty every time afterwards.

Getting the most out of your flashlight

Everyday use

- Topping it up whenever it suits you is fine. There is no need to wait until it is empty.
- Do not leave it completely empty for weeks or months. A battery left at 0% for a long time can discharge so deeply that it will no longer charge.
- It is normal for it to get slightly warm while charging. Place it on a hard, open surface and do not cover it.
- Hang it from your bag, keys or in your tent with the lanyard so it is always at hand.

Storing it for a longer period

- Store it at about half charge (40 to 60%). This is the most relaxed state for a lithium battery.
- Top it up at least every 60 days, even when you are not using it.
- Keep it dry and at room temperature. Not in a hot car, in direct sunlight or next to a heater.

Cleaning

Use a soft, dry cloth. No water, detergents or solvents. Disconnect all cables first.

Safe use

Please read these points before use. Ignoring them may result in injury, fire or damage to the product.

- Keep the flashlight out of reach of children and only use it as described in this manual.
- The flashlight is waterproof to IP65: rain and water jets will not harm it. Do not immerse it and do not use it underwater. Close the port cover after charging.
- Do not use it outside 0 to 45 °C. Keep it away from heat sources and open flames.
- Do not use a damaged, deformed or swollen flashlight, or damaged cables.
- Do not insert objects into the ports, do not short-circuit them, do not drop it and do not open it yourself.
- Do not look directly into the light and do not shine it into the eyes of people or animals.
- Notice smoke, a strange smell or strong heat? Disconnect all cables immediately and stop using it. Please contact us.
- Never throw the flashlight into a fire: it may explode.

Allowed in hand luggage

This power bank has 18.5Wh. Power banks up to 100Wh may be taken on board in your hand luggage under IATA rules. Not in checked baggage. Always check the rules of your airline before you travel.

Troubleshooting

Problem	Solution
Light does not switch on	Charge the flashlight via USB-C and try again.
Rear light does not switch on	Press and hold the button for longer, until the rear light comes on.
Phone does not charge	Use the USB-A output and push the cable in firmly. Is the flashlight almost empty? Charge it first.
Flashlight does not charge	Try another USB-C cable or adapter.

Warranty and customer service

Your Banky is covered by the statutory warranty. Have a question, or is something not working as it should? Our team is happy to help. Email **info@banky.nl** and include your order number and the model of your flashlight.

Disposal at the end of its life

Do not dispose of the flashlight with household waste. Take it to a collection point for batteries and electronics so the materials can be reused.

banky

Questions about your flashlight?
info@banky.nl

Thank you for choosing Banky. Energetic regards, Team Banky