banky

USER MANUAL

# USB-C Charger 45W with 2 USB-C ports

45W | 2× USB-C | PD 3.0 and PPS | laptop and phone




Please read this manual before first use and keep it for future reference.

EAN 8720865564968

banky.nl

# Welcome to Banky

Thank you for choosing the Banky USB-C Charger 45W. A compact fast charger with 2 USB-C ports for your laptop, tablet and phone. This manual explains how to use it and keep it safe.

## In the box

Charger · This manual

## Product overview




1. USB-C port 1
2. USB-C port 2
3. EU plug

## Specifications

| Item | Value |
|---|---|
| **Power** | Up to 45W |
| **Ports** | 2× USB-C |
| **Both ports at once** | Up to 45W combined, shared intelligently |
| **Fast charging protocols** | USB PD 3.0, PPS and QC 4.0 |
| **Mains voltage** | 100 to 240V, 50/60Hz |
| **Plug** | EU |
| **Protection** | SafeCell against overcurrent, overvoltage and overheating |
| **Dimensions** | 76.8 × 48.8 × 25.7 mm |
| **Weight** | 50 grams |
| **Certifications** | CE, FCC and RoHS |

Specifications are subject to change without notice.

## Quick start

1. Plug the charger into a wall socket.
2. Connect your device with a USB-C cable. Charging starts automatically.
3. Charging two devices? Use both ports. The power is shared automatically.

### How fast it charges

With one device you get up to 45W. Enough for a MacBook Air, an iPad or a fast phone charge. The charger and your device agree on the speed together: your device never takes more than it can handle. For the highest speed, use a USB-C cable rated for at least 45W.

### Compatible with

- iPhone, Samsung Galaxy, Google Pixel and other USB-C phones
- iPad, Nintendo Switch and AirPods
- MacBook Air and other USB-C laptops up to 45W

## Safe use

Please read these points before use. Ignoring them may result in injury, fire or damage to the product.

- For indoor use in a dry place only. Not in the bathroom.
- Never plug the charger in with wet hands.
- Do not cover the charger while charging. It is normal for it to get slightly warm.
- Do not use a damaged charger or cable.
- Do not insert objects into the ports and do not open the charger yourself.
- Keep it out of reach of children.
- Unplug the charger when you will not use it for a long time.

## Troubleshooting

| Problem | Solution |
|---|---|
| **Device charges slowly** | 1) Use a USB-C cable rated for 45W.<br>2) When charging two devices, the power is shared. |
| **Device does not charge** | Push the cable in firmly, try the other port and another socket. |
| **Charger gets warm** | Slightly warm is normal. If it gets hot, unplug it and let it cool down. |

## Warranty and customer service

Your Banky is covered by the statutory warranty. Have a question, or is something not working as it should? Our team is happy to help. Email **info@banky.nl** and include your order number and the model of your charger.

## Disposal at the end of its life

Do not dispose of the charger with household waste. Take it to a collection point for batteries and electronics so the materials can be reused.

banky

Questions about your charger?
**info@banky.nl**

Thank you for choosing Banky. Energetic regards, Team Banky